

Division of Fleet Operations

5,000 Mile required PM schedule

Miles	Suggested preventive maintenance services	Miles	Suggested preventive maintenance services
5,000	Change oil and filter, lube chassis as required, check and fill all fluid levels, check tire pressure, rotate tires	65,000	Change oil and filter, lube chassis as required, check and fill all fluid levels, check tire pressure, rotate tires
10,000	Change oil and filter, lube chassis as required, check and fill all fluid levels, check tire pressure	70,000	Change oil and filter, lube chassis as required, check and fill all fluid levels, check tire pressure
15,000	Change oil and filter, lube chassis as required, check and fill all fluid levels, check tire pressure, rotate tires, check brake linings	75,000	Change oil and filter, lube chassis as required, check and fill all fluid levels, check tire pressure, rotate tires, check brake linings, service transmission
20,000	Change oil and filter, lube chassis as required, check and fill all fluid levels, check tire pressure	80,000	Change oil and filter, lube chassis as required, check and fill all fluid levels, check tire pressure
25,000	Change oil and filter, lube chassis as required, check and fill all fluid levels, check tire pressure, rotate tires, service transmission	85,000	Change oil and filter, lube chassis as required, check and fill all fluid levels, check tire pressure, rotate tires
30,000	Change oil and filter, lube chassis as required, check and fill all fluid levels, check tire pressure, check brake linings, replace only non-platinum spark plugs, replace air filter, replace fuel filter, replace emission filters, RWD only - repack front wheel bearings, FWD only - repack rear wheel bearings	90,000	Change oil and filter, lube chassis as required, check and fill all fluid levels, check tire pressure, check brake linings, replace only non-platinum spark plugs, replace air filter, replace fuel filter, replace emission filters, RWD only - repack front wheel bearings, FWD only - repack rear wheel bearings
35,000	Change oil and filter, lube chassis as required, check and fill all fluid levels, check tire pressure, rotate tires,	95,000	Change oil and filter, lube chassis as required, check and fill all fluid levels, check tire pressure, rotate tires
40,000	Change oil and filter, lube chassis as required, check and fill all fluid levels, check tire pressure	100,000	Change oil and filter, lube chassis as required, check and fill all fluid levels, check tire pressure, replace spark plugs, service transmission
45,000	Change oil and filter, lube chassis as required, check and fill all fluid levels, check tire pressure, rotate tires	105,000	Change oil and filter, lube chassis as required, check and fill all fluid levels, check tire pressure
50,000	Change oil and filter, lube chassis as required, check and fill all fluid levels, check tire pressure, service transmission	110,000	Change oil and filter, lube chassis as required, check and fill all fluid levels, check tire pressure, rotate tires
55,000	Change oil and filter, lube chassis as required, check and fill all fluid levels, check tire pressure, rotate tires	115,000	Change oil and filter, lube chassis as required, check and fill all fluid levels, check tire pressure,
60,000	Change oil and filter, lube chassis as required, check and fill all fluid levels, check tire pressure, check brake linings, replace only non-platinum spark plugs, replace air filter, replace fuel filter, replace emission filters, RWD only - repack front wheel bearings, FWD only - repack rear wheel bearings	120,000	Change oil and filter, lube chassis as required, check and fill all fluid levels, check tire pressure, check brake linings
		125,000	Change oil and filter, lube chassis as required, check and fill all fluid levels, check tire pressure, rotate tires, service transmission